







Installation manual

HO_2S




Element symbol	Dimensions	Code	Package
1	1200 551	tabl_2S.001	
2	727 550	tabl_2S.002	
3	784 280	tabl_2S.003	
4	366 514	tabl_2S.004	
5	366 60	tabl_2S.005	
6	727 550	tabl_2S.006	
7	431 550	tabl_2S.007	
8	366 514	tabl_2S.008	
9	514 366	tabl_2S.009	
10	326 502	tabl_2S.010	
11	360 173	tabl_2S.011	
12	500 110	tabl_2S.012	
13	500 110	tabl_2S.013	
14	308 110	tabl_2S.014	


4x		4x		2x		2x		4x		4x	
1x		25x		25x		25x		42x		24x	




3




1




4




2







7



8



5



6

