






























Assembly Instructions / Navodila za montažo /
Montageanleitungen

HUNTER















5



6



8

7

9

