

AssemblyInstructions/Navodilazamontažo/Montageanleitungen JAMAR



| | | | | |
|-----------------------------|-------------------------------|-------------------------------|----------------------------|-----------------------------|
| <p>A x1</p> <p>1 pieza</p> | <p>B x1</p> <p>1 pieza</p> | <p>C x2</p> | <p>D x1</p> | <p>E x1</p> |
| <p>F x1</p> | <p>G x1</p> | <p>H x5</p> | <p>I x1</p> <p>(5)mm</p> | <p>J x1</p> <p>(6)mm</p> |
| <p>L x1</p> | <p>M x1</p> | <p>N x1</p> | <p>O x6</p> | <p>1 x4</p> <p>(8x30)mm</p> |
| <p>2 x4</p> <p>(Φ20)mm</p> | <p>3 x6</p> <p>(6x30)mm</p> | <p>4 x4</p> <p>(6x16)mm</p> | <p>5 x6</p> <p>(Φ16)mm</p> | <p>6 x2</p> <p>(6x35)mm</p> |
| <p>7 x1</p> <p>(6x50)mm</p> | <p>8 x2</p> <p>(4.8x20)mm</p> | <p>9 x2</p> <p>(3.5x16)mm</p> | <p>10 x3</p> <p>(6)mm</p> | |

