



























- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod









| A | B | C1 | C2 | C3 | D |
|----|-----------|------|------|-----|-----|
| 1 | S504-0025 | 200 | 496 | 16 | 1/1 |
| 2 | S504-0026 | 200 | 496 | 16 | 1/1 |
| 3 | S504-1032 | 377 | 390 | 15 | 1/1 |
| 4 | S504-1033 | 377 | 390 | 15 | 1/1 |
| 5 | S504-2019 | 500 | 390 | 15 | 1/1 |
| 6 | S504-2020 | 500 | 390 | 15 | 1/1 |
| 7 | S504-5709 | 469, | 68 | 16 | 1/1 |
| 8 | S504-9002 | 387, | 479, | 2,5 | 1/1 |
| 9 | WSP-9257 | 439, | 358 | 2,5 | 1/1 |
| 10 | ZQ6-5044 | 429 | 97 | 15 | 1/1 |
| 11 | ZQ6-519 | 350 | 110 | 12 | 1/1 |
| 12 | ZQ6-520 | 350 | 110 | 12 | 1/1 |
| 13 | S504-4031 | 469, | 68 | 15 | 1/1 |













6




6 






7



8



Pflegehinweis!

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

